

Printer Tour ■ ■ ■



Graphical Display
User Interface



Feed/Pause/Enter
Button

Menu Navigation
Buttons (4 ea)



Sealed User Interface

Interface LEDs

Tear Edge

Label Exit
Slot

Label Platform
(Dispenser Option)

Label Backing Exit
(Dispenser Option)

Case Bottom

Clear Media
Window

Feed/Pause
Button

Case Top

Concentric
Hinges

Case Top
Latch

Power Switch





Printer Tour ■ ■ ■

